Cross Reference Guide

Brainchild L91 / Zesta ZEL-L91

Limit Controller

This guide is to help select replacements for Brainchild controllers with Zesta ZEL controllers. The ZEL user manual and datasheet should be consulted when selecting a replacement controller. Some cross-referenced model numbers may not have all of the inputs/output types and features of the original. If in doubt, please contact us.

How to use this guide:

To find your model number:

1. Press CTRL+F. The Search dialog box opens.
2. Type your model number in the box.
3. Press ENTER.

If you do not find your model number, or if you require assistance in selecting an appropriate replacement controller, please contact Zesta customer service at 1-800-755-5418, or info@zesta.com.

Brainchild Part Number	Equivalent Zesta ZEL Part Number
L91-4110	ZEL-L91-4110
L91-4111	ZEL-L91-4111
L91-4116	ZEL-L91-4116
L91-4117	ZEL-L91-4117
L91-4118	ZEL-L91-4118
L91-4119	ZEL-L91-4119
L91-411A	ZEL-L91-411A
L91-411B	ZEL-L91-411B
L91-411C	ZEL-L91-411C
L91-411D	ZEL-L91-411D
L91-411E	ZEL-L91-411E
L91-411F	ZEL-L91-411F
L91-4160	ZEL-L91-4160
L91-4161	ZEL-L91-4161
L91-4166	ZEL-L91-4166
L91-4167	ZEL-L91-4167
L91-4168	ZEL-L91-4168
L91-4169	ZEL-L91-4169
L91-416A	ZEL-L91-416A
L91-416B	ZEL-L91-416B
L91-416C	ZEL-L91-416C
L91-416D	ZEL-L91-416D
L91-416E	ZEL-L91-416E
L91-416F	ZEL-L91-416F
L91-5110	ZEL-L91-5110
L91-5111	ZEL-L91-5111
L91-5116	ZEL-L91-5116
L91-5117	ZEL-L91-5117
L91-5118	ZEL-L91-5118
L91-5119	ZEL-L91-5119
L91-511A	ZEL-L91-511A
L91-511B	ZEL-L91-511B
L91-511C	ZEL-L91-511C
L91-511D	ZEL-L91-511D
L91-511E	ZEL-L91-511E
L91-511F	ZEL-L91-511F
L91-5160	ZEL-L91-5160
L91-5161	ZEL-L91-5161
L91-5166	ZEL-L91-5166

Brainchild Part Number	Equivalent Zesta ZEL Part Number
L91-5167	ZEL-L91-5167
L91-5168	ZEL-L91-5168
L91-5169	ZEL-L91-5169
L91-516A	ZEL-L91-516A
L91-516B	ZEL-L91-516B
L91-516C	ZEL-L91-516C
L91-516D	ZEL-L91-516D
L91-516E	ZEL-L91-516E
L91-516F	ZEL-L91-516F